




How to make Whirlygig Wings




1. Make Cutting Jig. Rip a 54-degree angle on a 3" x 8" piece of 3/4" stock.




2. Layout the Whirlygig Wings on 3/4" x 1" x 8" blocks (1 LH & 1 RH REQ'D) and drill the 3/16" Dia. hole through.




3. Mount the Whirlygig Wing to the bevel with a 1-1/4" x #8 Round Head Wood Screw. Make the first cut on a bandsaw with a 1/8" blade.



4. Turn the Whirlygig Wing around the Wood Screw and make the second cut.



5. Remove the Wood Screw, turn the Whirlygig Wing over, reattach the Screw, and repeat Steps 3 and 4.



6. Completed Whirlygig Wing is now ready for sanding and balancing.